


---

# use & care guide

---




## COOKTOP AND LOWER OVEN

Continuous-Cleaning  
Model RM955PXP

---

Wave Ovens, Trash Compactors, Room Air Conditioners, Dehumidifiers, Automatic Washers, Clothes Dryers, Freezers, Refrigerator-Freezers



<b>Contents</b>		Page
<b>Before You Use Your Range</b>	The Storage Drawer	13
<b>Important Safety Instructions</b>	Optional Rotisserie	14
<b>Parts and Features</b>	<b>Caring for Your Cooktop and</b>	
<b>Using Your Range</b>	<b>Lower Oven</b>	14
Using the Surface Units	Control Panel and Knobs	14
Optional Accessory Conning Kit	Surface Units and Reflector Bowls	15
Setting the Clock	Lift-Up Cooktop	16
Using the Minute Timer	The Lower Oven Door	17
Using the Lower Oven	The Continuous-Cleaning Oven	17
Baking or Roasting	Cleaning Chart	20
Adjusting the Temperature Control	The Cooktop Light	21
Using the Automatic MEALTIMER* Clock	The Lower Oven Light	22
Broiling	<b>If You Need Service or Assistance</b>	22
The Oven Vent		

© 1985 Whirlpool Corporation

\*Tmk.

## Before you use your range

**Read and carefully follow the "INSTALLATION INSTRUCTIONS" packed with your range.**

Read this "Use & Care Guide" and your "Cooking Guide" carefully for important use and safety information. Store these with the Upper Microwave Oven literature in the Range Literature Pac for future use.

**It is your personal responsibility and obligation to be sure your range:**

- Has been installed where it is protected from the elements.
- Has been installed and leveled on a floor strong enough to support its weight.
- Has been properly connected to electrical supply and grounded. (See "Installation Instructions.")
- Is not used by anyone unable to operate it properly.
- Is properly maintained.
- Is used only for jobs expected of a home range.

**See your "Cooking Guide" and "Upper Microwave Oven Use & Care Guide" for additional safety and operating instructions.**

# IMPORTANT SAFETY INSTRUCTIONS



**WARNING** – When using your cooktop or lower oven, follow basic precautions, including the following:

- 1. DO NOT** allow children to use or play with any part of the range or leave them unattended near it. They could be burned or injured.
- 2. DO NOT** store things children might want above the range. Children could be burned or injured while climbing on it.
- 3. DO NOT** allow anyone to touch hot surface units or heating elements. Dark colored units and elements can still be hot enough to burn severely.
- 4. KEEP** children away from the range when it is on. The cooktop and oven walls, racks and door can get hot enough to cause burns.
- 5. DO NOT** use the range to heat a room. Persons in the room could be burned or injured, or a fire could start.
- 6. KEEP** pan handles turned in, but not over another surface unit to avoid burns, injury and to help prevent the utensil from being pushed off the surface units.
- 7. DO NOT** use water on grease fires. The fire will spread. Cover fire with large lid or smother with baking soda or salt.
- 8. DO NOT** wear loose or hanging garments when using the range. They could ignite if they touch a hot surface unit or heating element and you could be burned.
- 9. DO NOT** heat unopened containers. They could explode. The hot contents could burn and container particles could cause injury.
- 10. MAKE SURE** to open the oven door all the way when adding or removing food to prevent burns.


• FOR YOUR SAFETY •  
**DO NOT STORE OR USE GASOLINE OR OTHER FLAMMABLE VAPORS AND LIQUIDS  
IN THE VICINITY OF THIS OR ANY OTHER APPLIANCE. THEY COULD IGNITE  
CAUSING EXPLOSION AND/OR FIRE.**

**– SAVE THESE INSTRUCTIONS –**

# Parts and features

## Model RM955PXP

### COOKTOP AND LOWER OVEN



### Copy your Model and Serial Numbers here...

If you need service, or call with a question, have this information ready:

**1. Complete** Model and Serial Numbers (from the plate located behind the microwave oven door).

**2.** Purchase date from sales slip.  
Copy this information in these spaces. Keep this book in the Range Information Center with your warranty and sales slip.

There is no warranty registration to return. Proof-of-purchase is all that is required for in-warranty service.


Model Number \_\_\_\_\_

Serial Number \_\_\_\_\_


Purchase Date \_\_\_\_\_

Service Company/Phone Number \_\_\_\_\_

# Using your range




PARTS AND FEATURES • USING YOUR RANGE



**Surface unit control knobs must be pushed in before turning.** Turn either way until setting you want shows in window. Set them anywhere between HI and OFF.

## Indicator light



When a surface unit is on, its indicator light will also be on.



**WARNING:** Be sure all lights are OFF when you are not cooking. Someone could be burned or a fire could start if a surface unit is accidentally left ON.

## Using the surface units

Until you get used to the settings, use the following as a guide:

**Use HI** to start foods cooking or to bring liquids to a boil.

**Use MED-HI** to hold a rapid boil or to fry chicken or pancakes.

**Use MED** for gravy, puddings and icing, or to cook large amounts of vegetables.

**Use MED-LO** to keep food cooking after starting it on a higher setting.

**Use LO** to keep food warm until ready to serve. Set the heat higher or lower within the LO band to keep food at the temperature you want.

**CAUTION: The use of the HI setting for long periods of time can damage surface units and discolor chrome reflector bowls. Start cooking on HI and turn control down to continue cooking.**

Use only flat-bottomed utensils for best cooking result and to prevent damage to the cooktop. Specialty items with rounded or ridged bottoms (woks, ridged bottom canners or tea kettles) are not recommended.



**WARNING: The surface unit should never turn red during use. If it turns red, the bottom of the pan is not flat enough or is too small for the size of the surface unit. Damage to the surface unit, cooktop, wiring and/or surrounding area could result. If the pan is too small for the surface unit, you could be burned by the heat from the exposed section of the surface unit.**

See the “Cooking Guide” for important utensil information.

## Optional accessory canning kit (Part No. 242905)

The large diameter of most water-bath or pressure canners combined with high heat settings for long periods of time can shorten the life of regular surface units and cause damage to the cooktop.

If you plan to use the cooktop for canning, we recommend the installation of a Canning Kit. Order the kit from your Whirlpool Dealer or Tech-Care® Service Company.

See the “Cooking Guide” for important canning information.

## Setting the Clock

Push in and turn the Minute Timer Knob to set the Clock.



1. Push in Minute Timer Knob and turn clockwise until clock shows the right time of day.




2. Let the Minute Timer Knob pop out. Turn counterclockwise until Minute Timer dial shows OFF. The clock setting will change if you push in the knob when turning.


## Using the Minute Timer

The Minute Timer does not start or stop the oven. It works like a kitchen timer. Set it in minutes up to an hour. You will hear a buzzer when the set time is up.

**DO NOT PUSH IN THE KNOB** when setting the Minute Timer.



1. Without pushing it in, turn the Minute Timer Knob until the time showing in the window is longer than the setting you want.



2. Without pushing in, turn the knob back to the setting you want shows in the window.  
**When the time is up**, a buzzer will sound. To stop the buzzer, turn the dial to OFF.

**PUSHING IN AND TURNING THE MINUTE TIMER KNOB CHANGES THE CLOCK SETTING.**


## Using the lower oven

The lower oven is always set with two knobs:


- The Oven Selector
- The Oven Temperature Control

**Both must be on a setting for the oven to heat.**


## Baking or roasting



1. Position the rack(s) properly **before** turning on the oven. **To change rack position**, lift rack at front and pull out.




2. Set the Oven Selector on BAKE.



4. When the Lower Oven Indicator Light goes off, the oven is pre-heated. Put food in the oven. **Note: Oven racks, walls and door will be hot.**

Rack(s) should be placed so the top of the food will be centered in the oven. Always leave at least 1½ to 2 inches (4-5 cm) between the sides of the pan and the oven walls and other pans. For more information, see the "Cooking Guide."




3. Set the Oven Temperature Control to the baking temperature you want.
5. During baking, the elements will turn on and off to keep the oven temperature at the setting. The Lower Oven Indicator Light will turn on and off with the elements. **The top element helps heat during baking, but does not turn red.**  
When baking is done, turn **both** the Oven Selector and the Oven Temperature Control to OFF.




## Adjusting the Oven Temperature Control

Does your oven seem hotter or colder than your old oven? The Temperature of your old oven may have shifted gradually without your noticing the change. Your new oven is properly adjusted to provide accurate temperatures. But, when compared to your old oven, the new design may give you different results.


If after using the oven for a period of time, you are not satisfied with the temperature settings, they can be adjusted by following these steps:




1. Pull the Oven Temperature Control Knob straight off.



2. Loosen the locking screw inside the control knob. **Note the position of the notches.**



3. **To lower the temperature**, move a notch closer to LO. Each notch equals about 10°F (5°C).



4. **To raise the temperature**, move a notch closer to HI. Each notch equals about 10°F (5°C).

**Tighten the locking screw and replace the control knob.**


## Using the automatic MEALTIMER\* Clock

The automatic MEALTIMER Clock will turn the **lower oven** on and off at times you set...even when you are not around.

Automatic baking is ideal for foods which do not require a preheated oven such as meats and casseroles. **Do not use the automatic cycle for cakes, cookies, etc...undercooking will result.**

To start and stop baking automatically:

\*Tmk.




1. Position the oven rack(s) properly, and place the food in the oven.




2. Make sure the Clock is set to the right time of day.




3. Push in and turn the Start Time Knob **clockwise** to the time you want baking to start.



4. Push in and turn the Stop Time Knob **clockwise** to the time you want the oven to shut off.



5. Set the Oven Selector on TIMED.



6. Set the Oven Temperature Control on the baking temperature you want. The oven will now start and stop automatically.

**After baking is done or to stop the oven before the preset time,** turn both the Oven Selector and the Oven Temperature Control to OFF

**To start baking immediately and stop automatically:**

1. Position the oven rack(s) properly, and place the food in the oven.
2. Make sure the Clock is set to the right time of day.
3. Push in and turn the Stop Time Knob **clockwise** to the time you want the oven to shut off.
4. Set the Oven Selector on TIMED.
5. Set the Oven Temperature Control on the baking temperature you want.
6. After baking is done, turn **both** the Oven Selector and the Oven Temperature Control to OFF.



**To stop the oven before the preset time, turn both the Oven Selector and the Oven Temperature Control to OFF.**




**WARNING: To avoid sickness and food waste.**

- Use foods that will not go bad or spoil while waiting for cooking to start.
- Avoid using dishes with milk or eggs, cream soups, cooked meats or fish, or any item with baking powder or yeast.
- Any food that has to wait for cooking to start should be very cold or frozen before it is put in the oven. **MOST UNFROZEN FOODS SHOULD NEVER STAND MORE THAN TWO HOURS BEFORE COOKING STARTS.**


## Broiling



1. Position the rack properly for broiling. See broil chart in the "Cooking Guide" or a reliable cookbook.
2. Put the broiler pan and food on the rack.



3. Leave the door open about 4 inches (10.2 cm). The door will stay open by itself.



4. Set the Oven Selector and the Oven Temperature Control to BROIL.

When broiling is done, turn **both** the Oven Selector and the Oven Temperature Control to OFF.

## Custom Broil

- If food is cooking too fast, turn the Oven Temperature Control **counterclockwise** until the Lower Oven Indicator Light goes off.
- If you want the food to broil slower from the start, set the Oven Temperature Control between 150° and 325°F (65.5° and 162.7°C). The lower the temperature, the slower the cooking.

**The Oven Selector must be on BROIL for all broiling temperatures.**

**CAUTION: The oven door must be partly open whenever the oven is set to BROIL. Leaving the door open allows the oven to maintain proper temperatures and prevents window glass from cracking.**


## The Oven Vent

Hot air and moisture escape from the oven through a vent under the right rear surface unit. You can cook on the unit, or keep food warm on it while the oven is on.

**CAUTION: Plastic utensils left over the vent can melt.**



**WARNING: If you leave a utensil on the right rear surface unit, use pot holders when moving it. Pan handles can become hot enough to burn.**




**Do not block the vent.** Poor baking can result.


## The storage drawer

The storage drawer is for storing pots and pans.

### Removing the storage drawer




1. Pull drawer straight out to the first stop. Lift front and pull out to the second stop.




2. Lift back slightly and slide drawer all the way out.


### Replacing the storage drawer



1. Fit ends of drawer slide rails into the drawer guides on both sides of opening.



2. Lift drawer front and push in until metal stops on drawer slide rails clear white stops on drawer guides. Lift drawer front again to clear second stop and slide drawer closed.



### Use & Care Guide storage

Store this booklet, along with your "Cooking Guide," sales slip and warranty in the Literature Pac, inside the storage drawer.


## Optional Rotisserie

If you would like a rotisserie for your lower oven, you can order a kit (Part No. RCK 81-242985) from your Whirlpool Dealer. The kit includes easy installation instructions.

---

## Caring for your cooktop and lower oven


### Control Panel and Knobs




1. Pull knobs straight off. **NOTE:** Surface unit control knobs have a collar and a spring behind them.



2. Use warm soapy water or spray glass cleaner and a soft cloth to wipe the control panel. Rinse and dry well.




3. Wash control knobs and surface unit collars in warm soapy water. Rinse well and dry.




4. Push control knobs straight back on. Make sure they point to OFF. Make sure the collar and spring behind the surface unit control knobs are put together as shown.

## Surface units and reflector bowls


### Removing




-  **WARNING: To avoid burns and possible electric shock, be sure surface units are OFF and COOL.**



- Lift the edge of the unit, opposite the receptacle, just enough to clear the reflector bowl.




- Pull the surface unit straight away from the receptacle.




- Lift out the reflector bowl. See Cleaning Chart on page 20 for cleaning instructions.


### Replacing




-  **WARNING: To avoid burns and possible electric shock, be sure surface units are OFF.**



- Line up opening in the reflector bowl with the surface unit receptacle.



3. Hold the surface unit as level as possible with the terminal just started into the receptacle.



4. Push the surface unit terminal into the receptacle. When the terminal is pushed into the receptacle as far as it will go, the surface unit will fit into the reflector bowl.

**CAUTION: Reflector bowls reflect heat back to the utensils on the surface units. They also help catch spills. When they are kept clean, they reflect heat better and look new longer.**

**If a reflector bowl gets discolored, some of the utensils may not be flat enough, or some may be too large for the surface unit. In either case, some of the heat that's meant to go into or around a utensil goes down and heats the reflector bowl. This extra heat can discolor it. See "Cooking Guide" for further information.**



**WARNING – DO NOT LINE THE REFLECTOR BOWLS WITH FOIL. Shock or fire hazard could result.**


## Lift-Up Cooktop

1. Lift front of cooktop at center and swing-up the support rod.
2. Carefully lower the cooktop onto the support rod.



**WARNING: Be sure the rod fits in the notch in the cooktop and is held securely. The cooktop could accidentally fall and injure you.**

3. Wipe with warm soapy water. Use soapy steel-wool pad on stubborn spots.



**CAUTION: Do not drop the cooktop or let it bump the upper oven when lifting. Damage can result to the porcelain and the cooktop frame.**



## The Lower Oven Door


Removing the oven door will help make it easier to clean the oven.



**WARNING:** To avoid burns, be sure the oven is **OFF** and **COOL**.

1. Open the door to the first stop position.
2. Hold the door at both sides and lift **straight up**.
3. **To replace**, fit the bottom corners of the door over the ends of the hinges.



Push the door down evenly. The door will close only when it is on the hinges correctly.



## The Continuous-Cleaning Oven

Standard oven walls are coated with smooth porcelain-enamel. Your continuous-cleaning oven walls are coated with a special, rougher porcelain-enamel.


A fat spatter beads up on the smooth surface, but spreads out on the rougher surface. The bead of fat chars and turns black. The spread-out fat **gradually** burns away at **medium to high temperatures** (350°-475°F, 176°-246°C) so the oven can return to a presentably clean condition.



continued on next page


## Using Foil

Using foil on the oven bottom is recommended to catch sugar and starchy spills from pies and casseroles. **It must be used properly.** Cut foil from a roll of heavy-duty 18-inch (45 cm) aluminum foil, or buy a foil kit (Part No. 241430) from your Whirlpool Appliance dealer.



-  **WARNING: To avoid burns and possible electric shock, be sure the oven is OFF and COOL.**

Lift the cool bake element **slightly** to lift the feet off the oven bottom.




- 2. Slide the foil under the bake element.** Make sure the foil is centered, long enough to start up both sides and without wrinkles. For proper baking, **lower the bake element so all feet rest solidly on the foil.**


**CAUTION: Do not let foil touch the bake element. It could damage the element. Make sure foil is flat on the oven bottom and away from the bake element.**


## Cleaning Tips

- 1.** The oven window and racks are not coated. Clean them by hand.
- 2.** The oven door does not get as hot as the walls. Some hand cleaning may be needed.
- 3.** If you do more broiling than baking, hand cleaning may be needed.
- 4.** Use aluminum foil on the oven bottom according to instructions. Spillovers do not burn away and may stain the bottom.

## Hand Cleaning




 **WARNING: DO NOT USE OVEN CLEANING PRODUCTS.** Some can become trapped in the porcelain-enamel surface and give off harmful fumes.




**WINDOW** – Keep clean with hot sudsy water. Use a plastic scouring pad for stubborn spots. Rinse well.

**Do not use steel-wool or abrasive cleansers.**



**RACKS** – Use soapy steel-wool pad for best cleaning results. Rinse well.



**WALLS AND DOOR** – Wash with hot soapy water. Use a steel-wool pad or plastic scouring pad for stubborn spots. Rinse well.


## Cleaning Chart


PART	WHAT TO CLEAN	HOW TO CLEAN
<b>Exterior surfaces</b>	Soft cloth and warm soapy water. Nylon or plastic scouring pad for stubborn spots.	<ul style="list-style-type: none"> <li>• Wipe off regularly when cooktop and lower oven are cool.</li> <li>• <b>Do not allow food containing acids (such as vinegar, tomato, lemon juice or milk) to remain on surface. Acids will remove the glossy finish.</b></li> <li>• <b>Do not use abrasive or harsh cleansers.</b></li> </ul>
<b>Surface units</b>	No cleaning required.	<ul style="list-style-type: none"> <li>• Spatters or spills will burn off.</li> <li>• <b>Do not immerse in water.</b></li> </ul>
<b>Chrome reflector bowls</b>	Automatic dishwasher or warm, soapy water and plastic scrubbing pad.	<ul style="list-style-type: none"> <li>• Wash with other cooking utensils.</li> <li>• Clean frequently.</li> <li>• <b>Do not use abrasive or harsh cleansers.</b></li> </ul>
<b>Broiler pan and grid</b>	Warm, soapy water or steel wool pad.	<ul style="list-style-type: none"> <li>• Wash with other cooking utensils.</li> </ul>
<b>Control knobs</b>	Warm, soapy water and soft cloth.	<ul style="list-style-type: none"> <li>• Wash, rinse and dry well.</li> <li>• <b>Do not soak.</b></li> </ul>
<b>Control panel</b>	Warm, soapy water or spray glass cleaner.	<ul style="list-style-type: none"> <li>• Wash, rinse and dry well.</li> <li>• Follow directions provided with cleaner.</li> </ul>
<b>Oven racks</b>	Warm, soapy water or soapy steel wool pads.	<ul style="list-style-type: none"> <li>• Wash, rinse and dry. Use soapy steel wool pads for stubborn areas.</li> </ul>
<b>Lower oven door glass</b>	Spray glass cleaner, warm, soapy water or plastic scrubbing pad.	<ul style="list-style-type: none"> <li>• <b>Make sure oven is cool.</b></li> <li>• Follow directions provided with cleaner.</li> <li>• Wash, rinse and dry well with a soft cloth.</li> </ul>
<b>Continuous-Cleaning Oven</b>	Warm, soapy water or soapy scrubbing pad. Heavy-duty aluminum foil or order a foil kit (Part No. 241430) from your Whirlpool dealer or TECH-CARE™ service company.	<ul style="list-style-type: none"> <li>• Clean stubborn spots or stains. Rinse well with water.</li> <li>• Place strip of aluminum foil on the bottom of the oven to catch spillovers.</li> <li>• <b>Do not use commercial cleaners.</b></li> </ul> <p><b>Most fat spatters on the Continuous-Cleaning porcelain-enamel interior surface gradually reduce to a presentably clean condition during normal baking or roasting operations.</b></p>

## The Cooktop Light


The **Top Lite** button switch is at the bottom of the control panel. Push and hold the button for a few seconds before letting go to turn it ON. Push again to turn off the light.

To replace:




1.  **WARNING: To avoid possible shock hazard, turn off the electric power at the main power supply.**


Remove the 3 screws and metal trim that supports the top of the light cover. **The glass is heavy. Hold it securely.**



3. Grasp the fluorescent tube at both ends. Roll bottom of tube towards the front until both ends come out of the receptacles. Replace with a 20-watt cool-white fluorescent tube.



2. With both hands, pull top of light cover towards you and lift it out of bottom support trim.





4. With both hands, carefully fit the glass light cover into the bottom metal support trim. Replace the top support trim and screws. Turn the electric power back on at the main power supply.


## The Lower Oven Light

The oven light will turn on and off automatically when you open or close the oven door. To turn the light on when the oven door is closed, push the **Oven Lite** button at the bottom of the control panel. Push the button again to turn off the light.

### To replace the light bulb:



1.  **WARNING: To avoid possible shock hazard, turn off the electric power at the main power supply.**



2. Remove the light bulb from its socket. Replace the bulb with a 40-watt appliance bulb. Turn the power back on at the main power supply.

## If you need service or assistance, we suggest you follow these four steps:

### 1. Before calling for assistance...

Performance problems often result from little things you can fix yourself without tools of any kind.

#### If nothing operates:

- Is the power supply cord plugged into a live circuit with the proper voltage? (See "Installation Instructions.")
- Have you checked the main fuse or circuit breaker box?

#### If the oven will not operate:

- Is the Oven Selector turned to a setting (BAKE or BROIL, but not TIMED)?
- Is the Oven Temperature Control turned to a temperature setting?

#### If surface units will not operate:

- Have you checked the main fuse or circuit breaker box?

- Are surface units plugged in all the way?
- Do the control knobs turn?

#### If surface unit control knob(s) will not turn:

- Did you push in before trying to turn?
- Is the spring replaced as shown on page 14?

#### If soil is visible on Continuous-Cleaning oven finish:

- The special finish is designed to **gradually reduce oven soil** during normal baking or roasting. It is not designed to keep your oven spotless, only presentably clean.
- If you broil often, you may see oven soil.

- The door is cooler than the oven walls. Soil will be more visible on the door than other areas in the oven. See page 19 for how to clean.
- Sugar and starchy spills may leave stains. See page 19 for hand cleaning tips. **Keep foil on oven bottom to catch these spills.**

**If cooking results aren't what you expected:**

- Is the range level?
- Are you using pans recommended in the **Cooking Guide**?
- If baking, have you allowed 1½ to 2 inches (4-5 cm) on all sides of the pans for air circulation?
- Have you preheated the oven as the recipe calls for?
- Are the pans the size called for in the recipe?
- Are you following a tested recipe from a reliable source?
- Do the cooking utensils have smooth, flat bottoms and fit the surface unit being used?

See the **Cooking Guide** for more information on cooking problems and how to solve them.

**2. If you need assistance\*...**

Call Whirlpool **COOL-LINE**® service assistance telephone number. Dial free from:

**Continental U.S. . . (800) 253-1301**  
**Michigan . . . . . (800) 632-2243**  
**Alaska & Hawaii . (800) 253-4121**

and talk with one of our trained Consultants. The Consultants can instruct you in how to obtain satisfactory operation from your appliance or, if service is necessary, recommend a qualified service company in your area.

**3. If you need service\*...**



Whirlpool has a nationwide network of franchised **TECH-CARE**® Service Companies. **TECH-CARE** service technicians

are trained to fulfill the product warranty and provide after-warranty service, anywhere in the United States. To locate **TECH-CARE** service in your area, call our **COOL-LINE** service assistance telephone number (see Step 2) or look in your telephone directory Yellow Pages under:

APPLIANCES - HOUSEHOLD - MAJOR - SERVICE & REPAIR OR ELECTRICAL APPLIANCES - MAJOR - REPAIRING & PARTS  
 WHIRLPOOL APPLIANCES FRANCHISED TECH-CARE SERVICE OR WHIRLPOOL APPLIANCES FRANCHISED TECH-CARE SERVICE  
 SERVICE COMPANIES SERVICE COMPANIES  
 XYZ SERVICE CO XYZ SERVICE CO  
 123 Maple . . . . . 999-9999 123 Maple . . . . . 999-9999  
 OR  
 WASHING MACHINES, DRYERS & IRONERS - SERVICING  
 WHIRLPOOL APPLIANCES FRANCHISED TECH-CARE SERVICE  
 SERVICE COMPANIES  
 XYZ SERVICE CO  
 123 Maple . . . . . 999-9999

**4. If you have a problem\*...**

Call our **COOL-LINE** service assistance telephone number (see Step 2) and talk with one of our Consultants, or if you prefer, write to:

Mr. Stephen E. Upton  
 Senior Vice President  
 Whirlpool Corporation  
 Administrative Center  
 2000 US-33 North  
 Benton Harbor, MI 49022

\*If you must call or write, please provide: model number, serial number, date of purchase, and a complete description of the problem. This information is needed in order to better respond to your request for assistance.



FSP is a registered trademark of Whirlpool Corporation for quality parts. Look for this symbol of quality whenever you need a replacement part for your Whirlpool appliance. FSP replacement parts will fit right and work right, because they are made to the same exacting specifications used to build every new Whirlpool appliance.



Making your world a little easier.

Part No. 312876 Rev. A  
© 1985 Whirlpool Corporation

Printed in U.S.A.

---

matic Washers, Clothes Dryers, Freezers, Refrigerator-Freezers, Ice Makers, Dishwashers, Built-In Ovens and Surface Units, Ranges, Micro

