### GE Consumer & Industrial Appliances

## Assembly Instructions

# Advantium<sup>®</sup> 240V Built-In Accessory Storage Drawer JX2200, JX2201, ZX2201

#### **BEFORE YOU BEGIN**

Read these instructions completely and carefully. Read the Installation Instructions for the Advantium 240V oven completely and carefully for cutout dimensions and step-by-step instructions.

**IMPORTANT** — Save these instructions for local inspector's use.

**IMPORTANT** — Observe all governing codes and ordinances.

- **NOTE TO INSTALLER:** Be sure to leave these instructions with the Consumer.
- NOTE TO CONSUMER: Keep these instructions with your Advantium 240V Oven Owner's Manual for future reference.
- **SKILL LEVEL:** Installation of this appliance requires basic mechanical skills.
- **COMPLETION TIME:** One hour with the installation of an Advantium 240V oven.
- Proper installation is the responsibility of the installer.
- Product failure due to improper installation is not covered under the Warranty. See the Advantium 240V Oven Owner's Manual for warranty information.

#### MODELS AVAILABLE

#### Profile Models:


JX2200BB-Black
JX2201SS-Stainless Steel

#### Monogram Models:

ZX2201SS-Stainless Steel

NOTE: Advantium 240V Built-In Speedcook Oven model ZSC2202SS CANNOT be installed with an accessory storage drawer. See Installation Preparation Without an Accessory Storage Drawer in the Advantium 240V Built-In SpeedCook Oven Installation Instructions for this model.

#### PRODUCT DIMENSIONS AND CLEARANCES



NOTE: Appearance will vary by model.

#### **TOOLS REQUIRED**

• #2 Phillips screwdriver

#### PARTS SUPPLIED

- 2 Side Supports
- Screws
- · Screws (color matched)

#### ASSEMBLY TO ADVANTIUM 240V BUILT-IN SPEEDCOOK OVEN

#### 1 REMOVE PACKAGING AND PARTS

- Remove the drawer from the carton.
- Remove all packing material and tape.
- Open the drawer and remove any parts inside.
- · Locate parts.



Assembly Instructions



Side Supports (2)




Color Matched Screws (4 required, 1 extra)




Brass Screws (4 required, 2 extra)

#### 2 ASSEMBLING THE OVEN TO DRAWER

- A Place storage drawer on a surface with the front of drawer hanging over the edge of the surface. Not placing the front edge of drawer over the edge of the surface may result in damage to the drawer since the front edge of drawer hangs below the bottom of drawer.
- B Place the oven on top of the storage drawer.
  Make sure that the back and sides of the oven align with the back and sides of drawer.





**NOTE:** The bottom of the oven side flanges will sit directly in front of the top of the storage drawer side flanges.




## ASSEMBLING THE OVEN TO DRAWER (CONT.)

Remove the front two bottom screws on each side of the oven and the top center screw on each side of the storage drawer.





D Place the side supports into the tabs on the drawer and secure using the screws supplied and the screws removed in Step C.



E The oven and storage drawer assembly is now ready to be installed. Return to the Advantium 240V Built-In SpeedCook Oven Installation Instructions to complete the installation.

Printed in Korea 2