

**CAUTION: DISCONNECT ELECTRIC CURRENT BEFORE SERVICING. LABEL ALL WIRES PRIOR TO DISCONNECTION WHEN SERVICING CONTROLS. WIRING ERRORS CAN CAUSE IMPROPER AND DANGEROUS OPERATION. VERIFY PROPER OPERATION AFTER SERVICING.**

CAM	CIRCUIT	REGULAR				EX. RINSE		PERM. PRESS				KNITS & DELICATE			SOAK		PREWASH	
		WASH (15 MIN)	PUMP (6 MIN)	PUMP (15 MIN)	OFF	PUMP (9 MIN)	OFF	WASH (12 MIN)	PUMP (6 MIN)	PUMP (9 MIN)	OFF	WASH (6 MIN)	PUMP (6 MIN)	PUMP (6 MIN)	OFF	SOAK (12 MIN)	WASH (6 MIN)	PUMP (6 MIN)
0	2	1	T	FILL CONTROL														
	3	B	T	NOT USED														
2	5	4	T	WASH FILL														
	6	B	T	RINSE FILL														
4	8	7	T	WATER TEMP														
	9	B	T															
6	11	10	T	SPIN DIR														
	12	B	T	AGITATE DIR														
8	14	13	T	AGITATE DIR														
	15	B	T	SPIN DIR														
10	17	16	T	AGIT CONTROL														
	18	B	T	PUMP														
12	20	19	T	SPIN CONTROL														
	21	B	T	HIGH SPEED MOTOR														
14	23	22	T	SPIN CONTROL														
	24	B	T	LOW SPEED MOTOR														

