



Note: The illustration is explained the wire connection of the O.T.P of the external compressor. For the internal compressor, the O.T.P has been connected with the compressor.