
# Over the Range Microwave Oven

### **BEFORE YOU BEGIN**

Read these instructions completely and carefully.

- **IMPORTANT** Save these instructions for local inspector's use.
- IMPORTANT Observe all governing codes and ordinances.
- **Note to Installer** Be sure to leave these instructions with the Consumer.
- **Note to Consumer** Keep these instructions for future reference.
- **Skill level** Installation of this appliance requires basic mechanical and electrical skills.
- Proper installation is the responsibility of the installer.
- Product failure due to improper installation is not covered under the Warranty.



### **Need Help?**

For customers in the United States, call: 1-800-944-9044

For Canadian customers, call: 1-866-213-9397 (English)

1-800-668-4606 ext. 8199 (French)


READ CAREFULLY.
KEEP THESE INSTRUCTIONS.

CONTENTS
General information
Important Safety Instructions 3
Electrical Requirements 3
Hood Exhaust4-5
Damage - Shipment/Installation6
Parts Included 6
Tools You Will Need
Mounting Space
Step-by-step installation guide
Placement of Mounting Plate8-10
Removing the Mounting Plate8
Finding the Wall Studs
Determining Wall Plate Location9
Aligning the Wall Plate10
Installation Types
A Outside Top Exhaust12–14
Attach Mounting Plate to Wall12
Preparation of Top Cabinet13
Checking for Proper Damper Operation13
Mount the Microwave Oven13-14
Adjust the Exhaust Adaptor14
Connecting Ductwork14
<b>B</b> Outside Back Exhaust 15–18
Preparing Rear Wall for Outside Back Exhaust15–16
Attach Mounting Plate to Wall16
Preparation of Top Cabinet16
Adapting Microwave Blower for Outside Back Exhaust17
Mount the Microwave Oven18

<b>C</b> Recirculating19–22	
Attach Mounting Plate to Wall19	
Preparation of Top Cabinet19	
Check Microwave Assembly20	
Adapting Microwave Blower for Recirculation20–21	
Mount the Microwave Oven21–22	
Installing the Charcoal Filter22	
Before You Use Your Microwave23	

### **IMPORTANT SAFETY INSTRUCTIONS**

This product requires a three-prong grounded outlet. The installer must perform a ground continuity check on the power outlet box before beginning the installation to insure that the outlet box is properly grounded. If not properly grounded, or if the outlet box does not meet electrical requirements noted (under ELECTRICAL REQUIREMENTS), a qualified electrician should be employed to correct any deficiencies.




CAUTION: For personal safety, remove house fuse or open circuit breaker before beginning installation to avoid severe or fatal shock injury.

CAUTION: For personal safety, the mounting surface must be capable of supporting the cabinet load, in addition to the added weight of this 63-85 pound (28.6-38.6 kg) product, plus additional oven loads of up to 50 pounds (22.7 kg) or a total weight of 113-135 pounds (51.3-61.2 kg).

CAUTION: For personal safety, this product cannot be installed in cabinet arrangements such as an island or a peninsula. It must be mounted to BOTH a top cabinet AND a wall.

NOTE: For easier installation and personal safety, it is recommended that two people install this product. IMPORTANT—PLEASE READ CAREFULLY. FOR PERSONAL SAFETY, THIS APPLIANCE MUST BE PROPERLY GROUNDED TO AVOID SEVERE OR FATAL SHOCK.

The power cord of this appliance is equipped with a



three-prong (grounding) plug which mates with a standard three-prong (grounding) wall receptacle to minimize the possibility of electric shock hazard from this appliance. You should have the wall receptacle and circuit checked by a qualified electrician to make sure the receptacle is properly grounded.

Where a standard two-prong wall receptacle is encountered, it is very important to have it replaced with a properly grounded three-prong wall receptacle, installed by a qualified electrician.

DO NOT, UNDER ANY CIRCUMSTANCES, CUT, DEFORM OR REMOVE ANY OF THE PRONGS FROM THE POWER CORD. DO NOT USE WITH AN EXTENSION CORD.

## ELECTRICAL REQUIREMENTS


Product rating is 120 volts AC, 60 Hertz, 15 amps and 1.58 kilowatts. This product must be connected to a supply circuit of the proper voltage and frequency. Wire size must conform to the requirements of the National Electrical Code or the prevailing local code for this kilowatt rating. The power supply cord and plug should be brought to a separate 15 to 20 ampere branch circuit single grounded outlet. The outlet box should be located in the cabinet above the microwave oven. The outlet box and supply circuit should be installed by a qualified electrician and conform to the National Electrical Code or the prevailing local code.

### **HOOD EXHAUST**

NOTE: Read these next two pages only if you plan to vent your exhaust to the outside. If you plan to recirculate the air back into the room, proceed to page 6.

### OUTSIDE TOP EXHAUST (EXAMPLE ONLY)

The following chart describes an example of one possible ductwork installation.




DUCT PIECES		EQUIVALENT LENGTH	X	NUMBER USED	=	EQUIVALENT LENGTH
	Roof Cap	24 Ft. (7.32 m)	Х	(1)	=	24 Ft. (7.32 m)
	12 Ft. Straight Duct (6" Round)	12 Ft. (3.66 m)	Х	(1)	=	12 Ft. (3.66 m)
	Rectangular-to-Round Transition Adaptor*	5 Ft. (1.52 m)	Х	(1)	=	5 Ft. (1.52 m)
Equivalent length reflect requireme	ns of duct pieces are based or ents for good venting performa	n actual tests and ance with any ven	t hood.	Total Lengtl	n =	41 Ft. (12.50 m)

<sup>\*</sup>IMPORTANT: If a rectangular-to-round transition adaptor is used, the bottom corners of the damper will have to be cut to fit, using the tin snips, in order to allow free movement of the damper.

### **OUTSIDE BACK EXHAUST (EXAMPLE ONLY)**

The following chart describes an example of one possible ductwork installation.



	DUCT PIECES		EQUIVALENT   LENGTH*	x	NUMBER USED	=	EQUIVALENT LENGTH
7		Wall Cap	40 Ft. (12.19 m)	Х	(1)	II	40 Ft. (12.19 m)
		3 Ft. Straight Duct (31/4" x 10" Rectangular)	3 Ft. (91.44 cm)	Х	(1)	II	3 Ft. (91.44 cm)
		90° Elbow	10 Ft. (3.05 m)	Х	(2)		20 Ft. (6.10 m)
		s of duct pieces are based on nts for good venting performa		t hood.	Total Length	=	63 Ft. (19.20 m)

**NOTE:** For back exhaust, care should be taken to align exhaust with space between studs, or wall should be prepared at the time it is constructed by leaving enough space between the wall studs to accommodate exhaust.

**NOTE:** If you need to install ducts, note that the total duct length of  $3\frac{1}{4}$ " x 10" rectangular or 6" diameter round duct **should not exceed 140 equivalent feet (42.67 m).** 

Outside ventilation requires a HOOD EXHAUST DUCT. Read the following carefully.

**NOTE:** It is important that venting be installed using the most direct route and with as few elbows as possible. This ensures clear venting of exhaust and helps prevent blockages. **Also, make sure dampers swing freely and nothing is blocking the ducts.** 

### **Exhaust connection:**

The hood exhaust has been designed to mate with a standard  $3\frac{1}{4}$ " x 10" rectangular duct.

If a round duct is required, a rectangular-to-round transition adaptor must be used. **Do not use less than a 6**" diameter duct.

### Maximum duct length:

For satisfactory air movement, the total duct length of  $3\frac{1}{4}$ " x 10" rectangular or 6" diameter round duct **should not exceed 140 equivalent feet (42.67 m).** 

**etc.**, present additional resistance to airflow and are equivalent to a section of straight duct which is longer than their actual physical size. When calculating the total duct length, add the equivalent lengths of all transitions and adaptors plus the length of all straight duct sections. The chart below shows you how to calculate total equivalent ductwork length using the approximate feet of equivalent length of some typical ducts.

DUCT PIECES		EQUIVALENT LENGTH	х	NUMBER USED	=	EQUIVALENT LENGTH
	Rectangular-to-Round Transition Adaptor*	5 Ft. (1.52 m)	Х	( )	=	Ft. (m)
	Wall Cap	40 Ft. (12.19 m)	X	( )	=	Ft. (m)
	90° Elbow	10 Ft. (3.05 m)	Х	( )	=	Ft. (m)
	45° Elbow	5 Ft. (1.52 m)	Х	( )	=	Ft. (m)
	90° Elbow	25 Ft. (7.62 m)	X	( )	=	Ft. (m)
	45° Elbow	5 Ft. (1.52 m)	Х	( )	=	Ft. (m)
	Roof Cap	24 Ft. (7.32 m)	X	( )	=	Ft. (m)
	Straight Duct 6" Round or 31/4" x 10" Rectangular	1 Ft. (30.48 cm)	X	( )	=	Ft. (cm)
			Tota	al Ductwork	=	Ft. (m)



\* IMPORTANT: If a rectangular-to-round transition adaptor is used, the bottom corners of the damper will have to be cut to fit, using the tin snips, in order to allow free movement of the damper.

Equivalent lengths of duct pieces are based on actual tests and reflect requirements for good venting performance with any vent hood.

## DAMAGE - SHIPMENT/INSTALLATION

- If the unit is damaged in shipment, return the unit to the store in which it was bought for repair or replacement.
- If the unit is damaged by the customer, repair or replacement is the responsibility of the customer.
- If the unit is damaged by the installer (if other than the customer), repair or replacement must be made by arrangement between customer and installer.

### **PARTS INCLUDED**

### HARDWARE PACKET


PART	QUANTITY	
<b>Emminim</b>	Wood Screws (1/4" x 2")	2
	Toggle Bolts (and wing nuts) (¾6" x 3")	4
	3	
	Nylon Grommet (for metal cabinets)	2
	28" (71.12 cm) Pieces of Foam Tape	2

You will find the installation hardware contained in a packet with the unit. Check to make sure you have all these parts.


**NOTE:** Some extra parts are included.

### **ADDITIONAL PARTS**

PART	QUANTITY	
TOP CABINET TEMPLATE	Top Cabinet Template	1
INSTALLATION INSTRUCTIONS	Installation Instructions	1
	Separately Packed Grease Filters	2








### **NOTES:**

- The space between the cabinets must be 30" (76.2 cm) wide and free of obstructions.
- If the space between the cabinets is greater than 30" (76.2 cm), a Filler Panel Kit may be used to fill in the gap between the microwave oven and the cabinets. Your Owner's Manual contains the kit number for your model.
- This microwave oven is for installation over ranges up to 36" (91.44 cm)wide.
- If you are going to vent your microwave oven to the outside, see Hood Exhaust Section for exhaust duct preparation.
- When installing the microwave oven beneath smooth, flat cabinets, be careful to follow the instructions on the top cabinet template for power cord clearance.


### PLACEMENT OF THE MOUNTING PLATE

### A. REMOVING THE MICROWAVE OVEN FROM THE CARTON/ REMOVING THE MOUNTING PLATE

- Remove the installation instructions, filters, glass tray and the small hardware bag. Do not remove the Styrofoam protecting the front of the oven.
- Fold back all 4 carton flaps fully against carton sides. Then carefully roll the oven and carton over onto the top side. The oven should be resting in the Styrofoam.



- **3** Pull the carton up and off the oven.
- 4 Remove and properly discard plastic bags.



Remove the 2 screws from the mounting plate.

This plate will be used as the rear wall template and for mounting. You may discard these screws.

# B. FINDING THE WALL STUDS Wall Studs

- **1** Find the studs, using one of the following methods:
  - **A.** Stud finder a magnetic device which locates nails.


#### OR

- **B.** Use a hammer to tap lightly across the mounting surface to find a solid sound. This will indicate a stud location.
- After locating the stud(s), find the center by probing the wall with a small nail to find the edges of the stud. Then place a mark halfway between the edges. The center of any adjacent studs should be 16" or 24" (40.64 cm or 60.96 cm) from this mark.
- **3** Draw a line down the center of the studs.


THE MICROWAVE MUST BE CONNECTED TO AT LEAST ONE WALL STUD.

### C. DETERMINING WALL PLATE LOCATION UNDER YOUR CABINET


### Plate position – beneath flat bottom cabinet



### Plate position – beneath framed recessed cabinet bottom



### Plate position – beneath recessed bottom cabinet with front overhang




Your cabinets may have decorative trim that interferes with the microwave installation. Remove the decorative trim to install the microwave properly and to make it level.

#### THE MICROWAVE MUST BE LEVEL.

Use a level to make sure the cabinet bottom is level.

If the cabinets have a front overhang only, with no back or side frame, install the mounting plate down the same distance as the front overhang depth. This will keep the microwave level.

- 1 Measure the inside depth of the front overhang.
- 2 Draw a horizontal line on the back wall an equal distance below the cabinet bottom as the inside depth of the front overhang.
- 3 For this type of installation with front overhang only, align the mounting tabs with this horizontal line, not touching the cabinet bottom as described in Step D.




### 2 INSTALLATION TYPES (Choose A, B or C)

This microwave oven is designed for adaptation to the following three types of ventilation:


- A. Outside Top Exhaust (Vertical Duct)
- **B.** Outside Back Exhaust (Horizontal Duct)
- C. Recirculating (Non-Vented Ductless)

**NOTE:** This microwave is shipped assembled for Outside Top Exhaust (except for non-vented models). Select the type of ventilation required for your installation and proceed to that section.


### A OUTSIDE TOP EXHAUST (VERTICAL DUCT)



### B OUTSIDE BACK EXHAUST (HORIZONTAL DUCT)



### C RECIRCULATING (NON-VENTED DUCTLESS)




A Charcoal Filter Accessory Kit is required for the nonvented exhaust. (See your Owner's Manual for the kit number.)

### Α

### **OUTSIDE TOP EXHAUST (Vertical Duct)**

# INSTALLATION OVERVIEW A1. Attach Mounting Plate to Wall A2. Prepare Top Cabinet A3. Check Damper Operation A4. Mount Microwave Oven A5. Adjust Exhaust Adaptor A6. Connect Ductwork


### A1. ATTACH THE MOUNTING PLATE TO THE WALL



Attach the plate to the wall using toggle bolts. At least one wood screw must be used to attach the plate to a wall stud.

- **1** Remove the toggle wings from the bolts.
- Insert the bolts into the mounting plate through the holes designated to go into drywall and reattach the toggle wings to 34" (19.05 mm) onto each bolt.

### To use toggle bolts:



Place the mounting plate against the wall and insert the toggle wings into the holes in the wall to mount the plate.


**NOTE:** Before tightening toggle bolts and wood screw, make sure the tabs on the mounting plate touch the bottom of the cabinet when pushed flush against the wall and that the plate is properly centered under the cabinet.

**CAUTION:** Be careful to avoid pinching fingers between the back of the mounting plate and the wall.

Tighten all bolts. Pull the plate away from the wall to help tighten the bolts.

### **A2.** USE TOP CABINET TEMPLATE FOR PREPARATION OF TOP **CABINET**

You need to drill holes for the top support screws, a hole large enough for the power cord to fit through, and a cutout large enough for the exhaust adaptor.



- Read the instructions on the TOP CABINET TEMPLATE.
- Tape it underneath the top cabinet.
- Drill the holes, following the instructions on the TOP CABINET TEMPLATE.

**CAUTION:** Wear safety goggles when drilling holes in the cabinet bottom.

### A3. CHECK FOR PROPER DAMPER OPERATION

### **Exhaust Adaptor** (absent on models shipped **Blower Plate** for recirculation exhaust) Damper Back of Microwave

- Place the microwave in its upright position, with the top of the unit facing up.
- This microwave oven may be shipped assembled for top exhaust (adaptor installed) or for recirculation exhaust (adaptor absent).
- Make sure tape securing damper is removed and damper pivots easily before mounting microwave.
- You will need to make adjustments to assure proper alignment with your house exhaust duct after the microwave is installed.

### **MOUNT THE MICROWAVE OVEN**



FOR EASIER INSTALLATION AND PERSONAL SAFETY. WE RECOMMEND THAT TWO PEOPLE INSTALL THIS MICROWAVE OVEN.

### IMPORTANT: Do not grip or use handle during installation.


**NOTE:** If your cabinet is metal, use the nylon grommet around the power cord hole to prevent cutting of the cord.


**NOTE:** We recommend using filler blocks if the cabinet front hangs below the cabinet bottom shelf.


IMPORTANT: If filler blocks are not used, case damage may occur from over tightening screws.


**NOTE:** When mounting the microwave oven, thread power cord through hole in bottom of top cabinet. Keep it tight throughout Steps 1-3. Do not pinch cord or lift oven by pulling cord.


1 Lift microwave, tilt it forward, and hook slots at back bottom edge onto four lower tabs of mounting plate.

















### B OUTSIDE BACK EXHAUST (Horizontal Duct)

# INSTALLATION OVERVIEW B1. Prepare Rear Wall B2. Attach Mounting Plate to Wall B3. Prepare Top Cabinet B4. Adjust Blower B5. Mount the Microwave Oven






# B1. PREPARING THE REAR WALL FOR OUTSIDE BACK EXHAUST (continued)




- **9** Fit the exhaust adaptor into the house duct as shown. Make sure the exhaust adaptor (with the damper) is squared up in the house duct and lines up with the holes in the mounting plate.
- (71.12 cm) foam tape. Press the sticky side of the 28" (71.12 cm) foam tape. Press the sticky side onto the face of the exhaust adaptor. (Don't stretch the foam tape.)



Attach the other 28" (71.12 cm) foam tape to the front of the mounting plate around both of the exhaust openings where it will touch the microwave.


### B2. ATTACH THE MOUNTING PLATE TO THE WALL



Attach the plate to the wall using toggle bolts. At least one wood screw must be used to attach the plate to a wall stud.

- 1 Remove the toggle wings from the bolts.
- Insert the bolts into the mounting plate through the holes designated to go into drywall and reattach the toggle wings to \(^3\lambda''\) (19.05 mm) onto each bolt.

### To use toggle bolts:



Place the mounting plate against the wall and insert the toggle wings into the holes in the wall to mount the plate.


**NOTE:** Before tightening toggle bolts and wood screw, make sure the tabs on the mounting plate touch the bottom of the cabinet when pushed flush against the wall and that the plate is properly centered under the cabinet.

**CAUTION:** Be careful to avoid pinching fingers between the back of the mounting plate and the wall.

Tighten all bolts. Pull the plate away from the wall to help tighten the bolts.

# B3. USE TOP CABINET TEMPLATE FOR PREPARATION OF TOP CABINET

You need to drill holes for the top support screws and a hole large enough for the power cord to fit through.




- Read the instructions on the TOP CABINET TEMPLATE.
- Tape it underneath the top cabinet.
- Drill the holes, following the instructions on the TOP CABINET TEMPLATE.


**CAUTION:** Wear safety goggles when drilling holes in the cabinet bottom.

# B4. ADAPTING MICROWAVE BLOWER FOR OUTSIDE BACK EXHAUST


1 Remove and save screw that holds blower motor to microwave.



**2** Carefully pull out the blower unit. The wires will extend far enough to allow you to adjust the blower unit.



**3** Rotate blower unit counterclockwise 180°.





Gently remove the wires from the grooves.

Reroute the wires through grooves on other side of the blower unit.

Before Rerouting

After Rerouting







Wires Routed Through Right Side

Wires Routed Through Left Side

**5** Roll the blower unit 90° so that fan blade openings are facing out the back of the microwave.




**6** Place the blower unit back into the opening.



CAUTION: Do not pull or stretch the blower unit wiring. Make sure the wires are not pinched.

NOTE: The blower unit exhaust openings should match exhaust openings on rear of microwave oven.

Secure the blower unit to the microwave with the screw from Step 1.



**8** Replace the blower plate in the same position as before with the screw.

### B5. MOUNT THE MICROWAVE OVEN



FOR EASIER INSTALLATION AND PERSONAL SAFETY, WE RECOMMEND THAT **TWO PEOPLE INSTALL THIS MICROWAVE OVEN.** 

### IMPORTANT: Do not grip or use handle during installation.


**NOTE:** If your cabinet is metal, use the nylon grommet around the power cord hole to prevent cutting of the cord.

**NOTE:** We recommend using filler blocks if the cabinet front hangs below the cabinet bottom shelf.


IMPORTANT: If filler blocks are not used, case damage may occur from over tightening screws.

NOTE: When mounting the microwave oven, thread power cord through hole in bottom of top cabinet. Keep it tight throughout Steps 1–3. Do not pinch cord or lift oven by pulling cord.


Lift microwave, tilt it forward, and hook slots at back bottom edge onto four lower tabs of mounting plate




3 Insert a self-aligning screw through top center cabinet hole. Temporarily secure the oven by turning the screw at least **two full turns** after the threads have engaged. (It will be completely tightened later.) Be sure to keep power cord tight. Be careful not to pinch the cord, especially when mounting flush to bottom of cabinet.



- **4** Attach the microwave oven to the top cabinet.
  - **5** Insert 2 self-aligning screws through outer top cabinet holes. Turn two full turns on each screw.



Tighten the outer two screws to the top of the microwave oven. (While tightening screws, hold the microwave oven in place against the wall and the top cabinet.)




8 Install grease filters. See the Owner's Manual packed with the microwave.

### C


### **RECIRCULATING** (Non-Vented Ductless)

### **INSTALLATION OVERVIEW**

- C1. Attach Mounting Plate to Wall
- **C2.** Prepare Top Cabinet
- **C3.** Check Microwave Assembly
- C4. Adjust Blower
- C5. Mount the Microwave Oven
- C6. Install Charcoal Filter




### C1. ATTACH THE MOUNTING PLATE TO THE WALL



Attach the plate to the wall using toggle bolts. At least one wood screw must be used to attach the plate to a wall stud.

- **1** Remove the toggle wings from the bolts.
- Insert the bolts into the mounting plate through the holes designated to go into drywall and reattach the toggle wings to 3/4" (19.05 mm) onto each bolt.

### To use toggle bolts:



Place the mounting plate against the wall and insert the toggle wings into the holes in the wall to mount the plate.

**NOTE:** Before tightening toggle bolts and wood screw, make sure the tabs on the mounting plate touch the bottom of the cabinet when pushed flush against the wall and that the plate is properly centered under the cabinet.

**CAUTION:** Be careful to avoid pinching fingers between the back of the mounting plate and the wall.

Tighten all bolts. Pull the plate away from the wall to help tighten the bolts.

# C2. USE TOP CABINET TEMPLATE FOR PREPARATION OF TOP CABINET

You need to drill holes for the top support screws and a hole large enough for the power cord to fit through.




- Read the instructions on the TOP CABINET TEMPLATE.
- Tape it underneath the top cabinet.
- Drill the holes, following the instructions on the TOP CABINET TEMPLATE.

**CAUTION:** Wear safety goggles when drilling holes in the cabinet bottom.


### **C3.** CHECK MICROWAVE ASSEMBLY

Exhaust Adaptor (absent on models shipped for recirculation exhaust)




- Place the microwave in its upright position, with the top of the unit facing up.
- The microwave oven may be shipped assembled for top exhaust (adaptor installed) or for recirculation exhaust (adaptor absent).
- If the microwave was shipped for recirculation exhaust, skip to C5. If shipped for top exhaust, proceed with C4.


### C4. ADAPTING MICROWAVE BLOWER FOR RECIRCULATION




3 Slide exhaust adaptor to one side and remove it. **NOTE:** The exhaust adaptor with damper is not needed for recirculating models. You may want to save them for possible future use.




Remove and save the screw that holds the blower motor to the microwave.





**5** Carefully pull out the blower unit. The wires will extend far enough to allow you to adjust the blower unit.



**6** Roll the blower unit 90° so that fan blade openings are facing toward the front of the microwave.









**NOTE:** Make sure wires remain routed in the grooves of the motor frame.

# C4. ADAPTING MICROWAVE BLOWER FOR RECIRCULATION (continued)

7 Place the blower unit back into the opening.
CAUTION: Do not pull or stretch the blower unit wiring. Make sure the wires are not pinched.



- 8 Secure blower unit to microwave with the screw removed in Step 4.
- **9** Replace blower plate with the screw removed in Step 1.



### C5. MOUNT THE MICROWAVE OVEN




FOR EASIER INSTALLATION AND PERSONAL SAFETY, WE RECOMMEND THAT TWO PEOPLE INSTALL THIS MICROWAVE OVEN.

### IMPORTANT: Do not grip or use handle during installation.


**NOTE:** If your cabinet is metal, use the nylon grommet around the power cord hole to prevent cutting of the cord.


**NOTE:** We recommend using filler blocks if the cabinet front hangs below the cabinet bottom shelf.

IMPORTANT: If filler blocks are not used, case damage may occur from over tightening screws.





Self-Aligning Screw






### **BEFORE YOU USE YOUR MICROWAVE**






- **2.** Remove all packing material from the microwave oven.
- **3.** Install turntable and ring in cavity.







164D3370P157

49-40165

12-00 JR Printed in Korea