## KitchenAid<sup>®</sup> Washer

## **PRODUCT MODEL NUMBERS**

## KAWS700J KAWS850J KAWS750J KAWS855J

**Electrical:** 120-volt, 60-Hz, AC-only, 15- or 20-amp. electrical supply. Use copper wire only. A time-delay fuse or circuit breaker and separate circuit is recommended.

