


**WARNING**  
 DISCONNECT POWER BEFORE SERVICING UNIT.

TRACER WIRE: WIRE COLOR NOTED FIRST, STRIPE NEXT. EXAMPLE: GREEN WIRE WITH YELLOW STRIPE.

**COLOR CODE**

|    |        |    |        |
|----|--------|----|--------|
| BK | BLACK  | P  | PINK   |
| BL | BLUE   | PR | PURPLE |
| BR | BROWN  | R  | RED    |
| C  | COPPER | T  | TAN    |
| G  | GREEN  | V  | VIOLET |
| GY | GRAY   | W  | WHITE  |
| O  | ORANGE | Y  | YELLOW |



**NOTES:**

- CIRCUIT SHOWN WITH ALL CONTROLS SET TO OFF. OVEN DOOR CLOSED AND UNLOCKED.
- COMPONENTS WITH \* DO NOT APPEAR ON ALL MODELS.

316255326