



- NOTES:
1. CIRCUIT SHOWN WITH ALL CONTROLS SET TO OFF.
OVEN DOOR CLOSED AND UNLOCKED.
 2. COMPONENTS WITH * DO NOT APPEAR ON ALL MODELS.

316002168

CAM POSITION	LOCK MOTOR SWITCH CONTACTS			
	A		B	
	COM-NC	COM-NO	COM-NC	COM-NO
UNLOCKED	N/A		N/A	X
LOCKING	N/A		N/A	
LOCKED	N/A	X	N/A	
UNLOCKING	N/A		N/A	