电路图说明书 1.7 DB USA-261800314777
客版英文，普通双胶纸,210*297MM



NOTE:For models - 790.80343,790.80349,790.80342

[CONDITION]			
DOOR:CLOSED	OL :OVEN LAMP	OG:ORANGE	BR:BROWN
COOK:OFF	FM :FAN MOTOR	YW:YELLOW	WH:WHITE
	TTM :TURNTABLE MOTOR	RD:RED	BK:BLACK
	SM :STIRRER MOTOR	BL:BLUE	GY:GREY
	CL :COOKTOP LAMP	GN:GREEN	PK:PINK

HOOD THERMAL NORMALLY OPEN(70C/158F):It's normally open, until the temperature is over than 158F, it's ON.

PN:316495122
261800314777