


Installation Instructions



Whirlpool

Home Appliances

IMPORTANT:


Installer: Leave Installation Instructions with the homeowner.

Homeowner: Keep Installation Instructions for future reference.

Save Installation Instructions for local electrical inspector's use.

30" Eye-Level Gas Range


Washers, Clothes Dryers, Freezers, Refrigerators-Freezers, Ice Makers, Dishwashers, Built-In Ovens and Surface Units, Ranges, Microwave Ovens, Compactors, Room Air Conditioners, Dehumidifiers, Automatic Washers, Clothes Dryers, Freezers, Refrigerators-Freezers, Ice Makers, Dishwashers, Built-In Over



Before you start...

Proper installation is your responsibility. Make sure you have everything necessary for correct installation. It is the responsibility of the installer to comply with the installation clearance specified on the serial/rating plate. The serial rating plate can be found under the cooktop.

ALL OPENINGS IN THE WALL OR FLOOR WHERE THE RANGE IS TO BE INSTALLED MUST BE SEALED.



Cabinet opening dimensions that are shown must be used. Given dimensions provide required 0" clearance.

Note: Clearances specified are for combustible walls and materials that have a density of 20 or more pounds per cubic foot. No evaluation of clearances has been made for installations adjacent to materials that are less than 20 pounds per cu. ft. or to plastic tiles and sheeting.

Check location where range will be installed. The location should be away from strong draft areas, such as windows, doors, and strong heating vents or fans. The range should be located for convenient use in the kitchen. Recessed installations must provide complete enclosure of the sides and rear of range.

WARNING: Reaching over heated surface burners causes risk of being burned. To reduce risk, installation of cabinet storage above surface units should be avoided.

If cabinets are already provided, reduce hazard by installing a range hood. Hood should extend beyond cabinets by a minimum of 5".

Important: Observe all governing codes and ordinances.

Proper gas supply connection must be available. See Gas supply requirements.

Overall height - 66" without optional hood
71-1/2" with optional hood

Grounded electrical outlet is required. See Electrical requirements.

FOR YOUR SAFETY
Do not obstruct the flow of combustion and ventilation air.

FOR YOUR SAFETY
The maximum gas supply pressure for this gas range must not exceed 14 inches W.P.C.

FOR YOUR SAFETY
If you smell gas:
1. Open windows.
2. Don't touch electrical switches.
3. Extinguish any open flame.
4. Immediately call your gas supplier.

FOR YOUR SAFETY
Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.

WARNING:
It is the customer's responsibility:
• To contact a qualified electrical installer.
• To assure that electrical installation is adequate and in conformance with National Electrical Code, ANSI/NFPA 70-1987* and local codes and ordinances.

Mobile home installation


The installation of this range must conform to the Manufactured Home Construction and Safety Standards, Title 24 CFR, Part 3280 (formerly the Federal Standard for Mobile Home Construction and Safety, Title 24, HUD, Part 280).

When range is installed in a mobile home, it must be secured to the floor during transit. Any method of securing the range is adequate as long as it conforms to the standards listed above.

Copies of the standards listed above may be obtained from:

- * National Fire Protection Association
Battery March Park
Quincy, Massachusetts 02169
- ** American Gas Association
1515 Wilson Boulevard
Arlington, Virginia 22209


Tools needed for installation:



Gas supply requirements

Observe all governing codes and ordinances.

A. This installation must conform with local codes and ordinances. In the absence of local codes, installations must conform with American National Standard, National Fuel Gas Code ANSI Z223.1-1984*



B. Input ratings shown on the serial/rating plate are for elevations up to 2,000 feet. For elevations above 2,000 feet, ratings should be reduced at a rate of 4% for each 1,000 feet above sea level.


C. This range is equipped for use with NATURAL gas. It is design-certified by A.G.A. for NATURAL and L.P. gases with appropriate conversion. The serial/rating plate located under the cooktop has information on the type of gas that can be used. If this information does not agree with the type of gas available, check with the local gas supplier. See Panel E for L.P. gas conversion instructions.

D. Provide a gas supply line of 3/4" rigid pipe to the range location. A smaller size pipe on long runs may result in insufficient gas supply. Pipe-joint compounds, resistant to the action of L.P. gas, must be used. With L.P. gas, piping or tubing size can be 1/2" minimum. L.P. gas suppliers determine the size and materials used on the system.




E. If local codes and ordinances permit, A.G.A.-approved, flexible metal tubing is recommended for connecting this range to the gas supply line. Do Not kink or damage the flexible tubing when moving the range. A 1/2" male pipe thread is needed for connection to pressure regulator female pipe threads.

WARNING: To prevent gas leaks and fire hazards, Do Not reuse an old, flexible gas line from your previous range. Purchase a new one.



F. The supply line shall be equipped with a shut-off valve. This valve should be located in the same room as the range and should be in a location that allows ease of opening and closing. Do Not block access to shut-off valve.



G. If rigid pipe is used as a gas supply line, a combination of pipe fittings must be used to obtain an in-line connection to the range. All strains must be removed from the supply and fuel lines so range will be level and in line.

H. The inlet pressure to the regulator should be as follows for both the operation and checking regulator setting:

NATURAL GAS:
Minimum pressure 6 inches
Maximum pressure 14 inches
L.P. GAS:
Minimum pressure 11 inches
Maximum pressure 14 inches

I. Line Pressure Testing:

Testing above 1/2 lb psi (gauge)
The range and its individual shut-off valve must be disconnected from the gas supply piping system during any pressure testing of that system at test pressures greater than 1/2 psig (3.5 kPa).

Testing at 1/2 lb psi (gauge)
The range must be isolated from the gas supply piping system by closing its individual manual shut-off valve during any pressure testing of the gas supply piping system at test pressures equal to or less than 1/2 psig (3.5 kPa).

Electrical requirements

WARNING: Improper connection of the equipment-grounding conductor can result in a risk of electrical shock. Check with a qualified electrician or serviceman if you are in doubt as to whether the appliance is properly grounded.

A 120 volt, 60 Hz, AC only, 15 ampere, fused electrical supply is required. A time-delay fuse or circuit breaker is recommended. It is recommended that a separate circuit serving only this appliance be provided.


A wiring diagram is included in these instructions. The wiring diagram is also located on the back of the range.

WARNING: AN EXTENSION CORD SHOULD NOT BE USED WITH THIS APPLIANCE. SUCH USE MAY RESULT IN A FIRE, ELECTRICAL SHOCK, OR OTHER PERSONAL INJURY.

Recommended grounding method


DO NOT, UNDER ANY CIRCUMSTANCES, REMOVE THE POWER SUPPLY CORD GROUNDING PRONG.

For your personal safety, this appliance must be grounded. This appliance is equipped with a 3-prong grounding plug. To minimize possible shock hazard, the cord must be plugged into a mating 3-prong, grounding-type wall receptacle, grounded in accordance with the National Electrical Code, ANSI/NFPA 70-1987* and local codes and ordinances. See Figure 1. If a mating wall receptacle is not available, it is the personal responsibility and obligation of the customer to have a properly grounded, 3-prong wall receptacle installed by a qualified electrician.




Temporary grounding method

If changing and properly grounding the wall receptacle is impossible and where local codes permit (consult your electrical inspector), a temporary adapter may be plugged into the existing 2-prong wall receptacle to mate with the 3-prong power supply cord. See Figure 2.




* Grounded cold water pipe must have metal continuity to electrical ground and not be interrupted by plastic, rubber or other electrically insulating connectors such as hoses, fittings, washers or gaskets (including water meter or pump). Any electrical insulating connector should be jumped as shown with a length of No. 4 wire securely clamped to bare metal at both ends.



Now start...

With range in kitchen.

1. Remove racks and other parts from inside ovens.



2. Place one foot on the shipping base. Tilt range forward slightly to free rear legs. Gently lower range to floor. Tilt range backwards until front legs are free.

Use caution when tilting the range. The added weight of the upper oven will make range unstable when tilted.

3. Remove shipping materials, tape and protective film from range. Do not remove cardboard shipping base at this time.


4. Adjust the leveling legs to a point where the range base does not touch the floor.

5. Plug the electrical cord into the grounded outlet.


Use caution when moving this appliance to prevent damage to floor coverings. Before moving, make sure cardboard shipping piece is under range to prevent floor damage.

6. Move the range closer to cabinet opening. Remove cardboard shipping piece from under range. Move range into cabinet opening and center.


7. It is recommended that this gas range be secured to the wall or floor. If installing this range in a mobile home, you MUST secure the range to the floor. Any method of securing the range is adequate as long as it conforms to the standards listed in Mobile home installation instructions, Panel A.




8. Place rack in lower oven. Place level on rack, first side to side, then front to back. If the range is not level, remove the storage drawer; then adjust the legs up or down as needed. Note: Oven must be level for satisfactory baking conditions. If range is secured to the floor, washers can be added to level the range. Tighten screws that secure range to wall or floor.



9. Remove storage drawer. Assemble the flexible connector from the gas supply pipe to the pressure regulator in this order: 3/4" nipple, 3/4" to 1/2" reducer, 1/2" nipple, manual shutoff valve, 1/2" nipple, union, and 1/2" nipple.



WARNING: THE REGULATOR IS DIE CAST. IF THE CONNECTION IS MADE TOO TIGHT, IT WILL CRACK RESULTING IN A GAS LEAK AND POSSIBLE FIRE OR EXPLOSION.




10. Use pipe-joint compound resistant to the action of L.P. gas to seal all gas connections. Check that the shutoff valve is open between the regulator and gas valves. If flexible connectors are used, be certain connectors are not kinked.

11. Open the shutoff valve in the gas supply line. Wait a few minutes for gas to move through the gas line.


12. Use a brush and liquid detergent to test all gas connections for leaks. Bubbles around connections will indicate a leak. If a leak appears, shut off gas valve controls and adjust connections. Then check connections again. **NEVER TEST FOR GAS LEAKS WITH A MATCH OR OTHER FLAME.** Clean all detergent solution from range.

Electronic Ignition System

Electronic ignition systems operate within wide voltage limits, but proper grounding and polarity is necessary. In addition to checking that the outlet provides 120-volt power and is correctly grounded, the outlet must be checked by a qualified electrician to see if it is wired with correct polarity.




Cooktop and oven burners use electronic igniters in place of standing pilots. When the cooktop control is turned to the "LITE" position, the system creates a spark to light the burner. This sparking continues until the control is turned to the desired setting. When the oven control is turned to the desired setting, a glow bar heats up bright orange and ignites the gas. No sparking occurs and the glow bar remains on while the burners operate.




13. Check the operation of the cooktop burners. Push in and turn each control knob to "LITE" position. The flame should light within 4 seconds. **Do Not leave the knob in the "LITE" position after burner lights.**



14. After burner lights, turn control knob to "Hi" position. Check each cooktop burner for proper flame. The small inner cone should have a very distinct blue flame 1/4" to 1/2" long. The outer cone is not as distinct as the inner cone.



15. If burners need adjusting for proper flame, adjust the air shutter to the widest opening that will not cause the flame to lift or blow off the burner. Repeat as necessary with each burner.




16. Check the operation of the lower oven burner. Push in and turn the oven control knob to 300°F. **The oven burner should light in 50 to 60 seconds. This delay is normal.** The oven safety valve requires a certain time before it will open and allow gas to flow.

Do Not attempt to insert any object into the openings of the protective shield that surrounds the igniter coil. Do not clean this area.

17.

Check the lower oven burner for proper flame. This flame should be 1/2" long, with inner cone of bluish-green, an outer mantle of dark blue and should be clean and soft in character. No yellow tips, blowing or lifting of flame should occur.



19. Check the operation of the lower oven broil burner. Push in and turn the oven control knob to "BROIL". The oven broil burner should light in 50 to 60 seconds. This delay is normal. The oven safety valve requires a certain time before it will open and allow gas to flow.


20. No adjustment of the oven broil burner is necessary. The hazy appearance of the flame is normal for this type of burner.

21. Repeat Steps 16-20 for the upper oven.

You have just finished installing your new Whirlpool range. To get the most efficient use from your new range, read your Whirlpool


Congratulations!

Use & Care Guide. Keep Installation Instructions and Guide close to range for easy reference. The instructions will make reinstalling your Whirlpool range in another home as easy as the first installation.



18.

If oven flame needs to be adjusted, remove the drawer and locate the air shutter near the center rear of the range, next to the pressure regulator. Loosen screw and adjust the air shutter until the proper flame appears. Tighten screw. Replace drawer, oven bottom and oven racks.



THERMOSTAT EA39A				
DIAL POSITION	7-8	C-NC	C-NO	1-2
OFF	O	N.S.	N.S.	N.S.
BAKE	X	N.S.	N.S.	CYCLES
BROIL	X	N.S.	N.S.	CYCLES
CLEAN	O	X	Y	CYCLES
		ABOVE 700°	BELOW 700°	

X = CLOSED
O = OPEN
N.S. = NOT SPECIFIED

CLOCK-TIMED OPERATION			
CONDITION	SETUP	1-2	3-4
OFF	BOTH KNOBS OUT	OPEN	OPEN
START NOW	SET STOP TIME	CLOSED	CLOSED
DELAY START	SET START & STOP TIMES	CLOSED	CLOSED

* CLOSED ONLY BETWEEN START TIME & STOP TIME SETTINGS.

SELECTOR SW SCHEDULE	
POSITION	CONTACTS
OFF	A, B, C & D OPEN
BAKE	A-2, B-5, C & D OPEN
TIMED BAKE	A-3, B-5, C & D OPEN
BROIL	A-1, B-5; C & D OPEN
CLEAN	A-4, C-6, D-7; B OPEN

- NOTES
1. COLOR FLAGGING IS A COMMON PRACTICE WHEN TRACING WIRES. CHECK FOR FLAGS AT EACH TERMINATION.
 2. ALL REPLACEMENT WIRES MUST HAVE SAME RATINGS AS ORIGINAL WIRES.
 3. ALL WIRES SHALL BE IN BOX UNLESS OTHERWISE NOTED.
 4. SCHEMATIC CONDITIONS: SELECTOR IN BAKE THERMOSTAT OFF, LIGHTS OFF, CLOCK OFF, DOOR UNLATCHED & OPEN.

SCHEMATIC

35-059749-05-0

L.P. gas conversion

Converting to L.P. gas should be done by a qualified installer.

A.

Only a qualified installer should install or adjust your gas range.

Pressure Regulator:

The pressure regulator on your range may be one of five different types. Check Figures 3-7 to determine which pressure regulator you have to convert. Only follow the instructions that apply to that pressure regulator.




Figure 3

1. Remove the cap marked "NAT." and turn it over so it reads "L.P." Then replace the cap. Do not disturb or remove the spring beneath the cap. Check that the fiber washer is between the cap and the body of the regulator. See Figure 3 for the correct position of the cap.




Figure 4

2. Remove the cap with screwdriver slot; turn it over; then replace the cap. This cap will then have the marking "LPG10." Do not disturb or remove the spring beneath this cap. See Figure 4.




Figure 5

3. Remove the cap with screwdriver slot. Remove the black insert marked "NAT." from the cap (the insert fits very tightly). Reverse the insert and push it firmly back into the cap. The marking "L.P." should appear on the insert. Be sure the insert is pressed into the shoulder. Do not disturb the spring in the body of the regulator. Replace the cap in the body of the regulator and tighten. See Figure 5.




Figure 6

4. Remove the cap with screwdriver slot. Carefully remove the spring, then the washer. Place the spring on the regulator first, then the washer. Replace the cap over the washer and spring. Tighten cap. See Figure 6.






Figure 7

5. Use a wrench to unscrew the cap from the top by turning counterclockwise. Turn the cap over so the hole end is up. Replace the cap and gasket on the regulator. DO NOT REMOVE THE PRESSURE REGULATOR.


B. After the gas line is connected, check for leaks. Use a brush and liquid detergent to test all gas connections for leaks. Bubbles around connections will indicate a leak. If a leak appears, shut off gas valve controls and adjust connections. Then check connections again. **NEVER TEST FOR GAS LEAKS WITH A MATCH OR OTHER FLAME.**



C.

Cooktop burners:

Screw the orifice hoods down until tight (approximately 2 to 2 1/2 turns). DO NOT OVERTIGHTEN. The burner flames cannot be properly adjusted if this conversion is not made. Adjust the air shutters for proper flame. See Panel C, Step 15. L.P. gas has a slightly yellow tip on top of burner flames in addition to the other proper characteristics.




D. Broil burner: To convert the broil burner from Natural to L.P. gas, the burner orifice spud must be changed. The L.P. gas burner orifice spud is found under the vent grill in the center of the burner box under the cooktop. BE SURE to use the proper burner spud for gas in use.

1. Remove the two screws fastening the broil burner assembly to the oven. Carefully pull the burner towards you then downward to access the burner orifice spud in the rear wall. Extra care is needed to avoid breaking the igniter coil. Place burner, screen-side-up, in a safe area.

2. Use a 5/16" nut driver to remove the Natural gas burner orifice spud. Install the L.P. burner orifice spud. Place the Natural gas burner orifice spud in the burner box for future conversion.

3. Replace the vent grill. Replace the burner assembly cover with louver facing the rear of the range.



E.

Oven burner: Remove drawer, oven racks and lower panel from oven bottom. Screw the orifice hood down until tight (approximately 2 to 2 1/2 turns). DO NOT OVERTIGHTEN. The burner flame cannot be adjusted properly if this conversion is not made. The burner flame should be 1/2" long when air shutter is correctly adjusted. Adjust the air shutter as needed for proper flame. See Panel D, Step 18. Replace drawer, oven bottom and racks.

Check Steps 19 and 20 for correct operation of the broil burner.

F.

Repeat steps D and E for upper oven.

G.

After the burners have been converted to L.P. gas usage, check for leaks as in Step B.

If installing optional vent hood...

To install optional vent hood above conventional eye-level range:

- A. Mount vent hood to top of range.
- B. Electrical power supply requires separate grounding circuit.
- C. See Vent hood installation instructions for proper ventilation and further electrical requirements.

If range does not operate...

Check that the circuit breaker is not tripped or the fuse blown. Check that the power supply cord is plugged into wall receptacle. Check that gas valve is turned to the "on" position.

If you need assistance...

During normal business hours, the Whirlpool COOL-LINE® Service will answer any questions about operating or maintaining your range not covered in the Installation Instructions. The Whirlpool COOL-LINE® Service number is (800) 253-1301. Dial just as you normally dial long distance — the call is free.

When you call, you need the range model number and serial number. Both numbers can be found on the serial/rating plate located under the cooktop.

If you need service...

In the event your Whirlpool appliance should need service, call the dealer from whom you purchased the appliance or a Whirlpool franchised TECH-CARE® service company. He is in the Yellow Pages of your phone directory listed under "Appliances — Household — Major — Service or Repair". You can also obtain his name and number by dialing, free, within the continental United States the Whirlpool COOL-LINE® Service number, (800) 235-1301. A special operator will tell you the name and number of your nearest Whirlpool TECH-CARE® service outlet.

Maintain the quality built into your Whirlpool appliance — call TECH-CARE®/service.

If you prefer to write...

Please include in your letter the model number, serial number, date of purchase and a complete description of your request or problem. This information will help us to provide exactly the assistance you need.

Address your letter to:

Mr. Robert Stanley
Division Vice President
Whirlpool Corporation
2000 M-63 North
Benton Harbor, MI 49022

