

CAUTION: DISCONNECT ELECTRIC CURRENT BEFORE SERVICING

TERM. A/C	CIRCUIT	REGULAR				EX. RINSE		PERM. PRESS				KNIVES & DELICATE				SOAK				
		WASH (15 MIN)	PUMP (6 MIN)	RINSE (3)	PUMP (15 MIN)	OFF	RINSE (3)	PUMP (9 MIN)	OFF	WASH (12 MIN)	PUMP (6 MIN)	RINSE (3)	PUMP (6 MIN)	OFF	WASH (6 MIN)	PUMP (6 MIN)	RINSE (3)	PUMP (6 MIN)	OFF	
0 2	1	LINE SWITCH																		
2 5	7	SPIN DIR																		
	9	AGITATE DIR																		
4 8	7	AGITATE DIR																		
	9	SPIN DIR																		
5 14	16L	ADV SOAK/WASH																		
6 14	17	EX. BYPASS																		
7 14	13L	ADV EXTRA RINSE																		
8 14	17	EX. BYPASS																		
9 8	13L	SPIN MOTOR																		
10 17	16	LD SW BYPASS																		
	18	PUMP																		
11 8	9	AGITATE MOTOR																		
12 20	19	WASH FILL																		
	24	RINSE FILL																		
13 5	6	MOTOR RUN																		
	22	WATER TEMP																		
14 23	24	SB SPRAY																		

CAUTION: DISCONNECT ELECTRIC CURRENT BEFORE SERVICING

