




CAUTION: DISCONNECT ELECTRIC CURRENT BEFORE SERVICING

TERM.	CIRCUIT	REGULAR	EXERCISE	PERM. PRESS	KNIT'S & DELICATE	SOAK	OFF
0	WATER TEMP	WASH (15 MIN)	PUMP (6 MIN)	PUMP (12 MIN)	OFF	WASH (6 MIN)	SOAK (12 MIN)
1	SIS SPRAY	PUMP (6 MIN)	PUMP (9 MIN)	PUMP (6 MIN)	PUMP (6 MIN)	PUMP (6 MIN)	PUMP (6 MIN)
2	WASH FILL	PUMP (6 MIN)	PUMP (9 MIN)	PUMP (6 MIN)	PUMP (6 MIN)	PUMP (6 MIN)	PUMP (6 MIN)
3	RINSE FILL	PUMP (6 MIN)	PUMP (9 MIN)	PUMP (6 MIN)	PUMP (6 MIN)	PUMP (6 MIN)	PUMP (6 MIN)
4	LD SW BYPASS	PUMP (6 MIN)	PUMP (9 MIN)	PUMP (6 MIN)	PUMP (6 MIN)	PUMP (6 MIN)	PUMP (6 MIN)
5	SPIN DIR	PUMP (6 MIN)	PUMP (9 MIN)	PUMP (6 MIN)	PUMP (6 MIN)	PUMP (6 MIN)	PUMP (6 MIN)
6	AGIATE DIR	PUMP (6 MIN)	PUMP (9 MIN)	PUMP (6 MIN)	PUMP (6 MIN)	PUMP (6 MIN)	PUMP (6 MIN)
7	ADV EXTRA RINSE	PUMP (6 MIN)	PUMP (9 MIN)	PUMP (6 MIN)	PUMP (6 MIN)	PUMP (6 MIN)	PUMP (6 MIN)
8	ADV SOAK/WASH	PUMP (6 MIN)	PUMP (9 MIN)	PUMP (6 MIN)	PUMP (6 MIN)	PUMP (6 MIN)	PUMP (6 MIN)
9	R.S. BYPASS	PUMP (6 MIN)	PUMP (9 MIN)	PUMP (6 MIN)	PUMP (6 MIN)	PUMP (6 MIN)	PUMP (6 MIN)
10	AGIATE MOTOR	PUMP (6 MIN)	PUMP (9 MIN)	PUMP (6 MIN)	PUMP (6 MIN)	PUMP (6 MIN)	PUMP (6 MIN)
11	PUMP	PUMP (6 MIN)	PUMP (9 MIN)	PUMP (6 MIN)	PUMP (6 MIN)	PUMP (6 MIN)	PUMP (6 MIN)
12	AGIATE DIR	PUMP (6 MIN)	PUMP (9 MIN)	PUMP (6 MIN)	PUMP (6 MIN)	PUMP (6 MIN)	PUMP (6 MIN)
13	ADV SOAK/WASH	PUMP (6 MIN)	PUMP (9 MIN)	PUMP (6 MIN)	PUMP (6 MIN)	PUMP (6 MIN)	PUMP (6 MIN)
14	R.S. BYPASS	PUMP (6 MIN)	PUMP (9 MIN)	PUMP (6 MIN)	PUMP (6 MIN)	PUMP (6 MIN)	PUMP (6 MIN)
15	AGIATE MOTOR	PUMP (6 MIN)	PUMP (9 MIN)	PUMP (6 MIN)	PUMP (6 MIN)	PUMP (6 MIN)	PUMP (6 MIN)
16	PUMP	PUMP (6 MIN)	PUMP (9 MIN)	PUMP (6 MIN)	PUMP (6 MIN)	PUMP (6 MIN)	PUMP (6 MIN)
17	AGIATE DIR	PUMP (6 MIN)	PUMP (9 MIN)	PUMP (6 MIN)	PUMP (6 MIN)	PUMP (6 MIN)	PUMP (6 MIN)
18	ADV SOAK/WASH	PUMP (6 MIN)	PUMP (9 MIN)	PUMP (6 MIN)	PUMP (6 MIN)	PUMP (6 MIN)	PUMP (6 MIN)
19	R.S. BYPASS	PUMP (6 MIN)	PUMP (9 MIN)	PUMP (6 MIN)	PUMP (6 MIN)	PUMP (6 MIN)	PUMP (6 MIN)
20	AGIATE MOTOR	PUMP (6 MIN)	PUMP (9 MIN)	PUMP (6 MIN)	PUMP (6 MIN)	PUMP (6 MIN)	PUMP (6 MIN)
21	PUMP	PUMP (6 MIN)	PUMP (9 MIN)	PUMP (6 MIN)	PUMP (6 MIN)	PUMP (6 MIN)	PUMP (6 MIN)
22	AGIATE DIR	PUMP (6 MIN)	PUMP (9 MIN)	PUMP (6 MIN)	PUMP (6 MIN)	PUMP (6 MIN)	PUMP (6 MIN)
23	ADV SOAK/WASH	PUMP (6 MIN)	PUMP (9 MIN)	PUMP (6 MIN)	PUMP (6 MIN)	PUMP (6 MIN)	PUMP (6 MIN)
24	R.S. BYPASS	PUMP (6 MIN)	PUMP (9 MIN)	PUMP (6 MIN)	PUMP (6 MIN)	PUMP (6 MIN)	PUMP (6 MIN)




TEMPERATURE SWITCH CIRCUIT

WASH/RINSE	F-H	FF-H	FF-C
COLD/COLD	0	0	X
WARM/COLD	X	0	X
HOT/COLD	0	X	0
WARM/WARM (OPT)	0	X	X

SPEED SWITCH CIRCUIT

AGIATE/SPIN	2-6	2-7	4-7	4-5
NIN	X	0	0	X
N/S	X	0	X	0
SIN (OPT)	0	X	X	X
SIS	0	X	X	0

N=NORMAL S=SLOW



WIRING DIAGRAM
 P/N 131973400