

CAUTION: DISCONNECT ELECTRIC CURRENT BEFORE SERVICING

CAM	TERM	CIRCUIT	REGULAR				OFF	EX. RINSE		OFF	PERM. PRESS				OFF	KNITS & DELICATE				OFF	SOAK				OFF
			WASH (15 MIN)	PUMP (6 MIN)	RINSE (10 MIN)	PUMP (12 MIN)		RINSE (10 MIN)	PUMP (9 MIN)		WASH (12 MIN)	PUMP (6 MIN)	RINSE (10 MIN)	PUMP (6 MIN)		WASH (6 MIN)	PUMP (6 MIN)	RINSE (10 MIN)	PUMP (6 MIN)		WASH (3)	SOAK (12 MIN)	RINSE (10 MIN)	PUMP (6 MIN)	
0	2	1	T																						
		3	B																						
2	5	4	T																						
		6	B																						
4	8	7	T																						
		9	B																						
6	11	10	T																						
		12	B																						
8	14	13	T																						
		15	B																						
10	17	16	T																						
		18	B																						
12	20	19	T																						
		21	B																						
14	23	22	T																						
		24	B																						

